Wind Sign II & Wind Sign Deluxe


"Quick-Change"™ Frame Assembly Instructions


See Reverse Side for **Snap Frame Instructions**



www.plasticade.com

Hardware Provided







Spring Assembly

- 1. Lay frame on its side and base on end as shown
- 2. Place washer on bolt fastener
- 3. Insert bolt fastener through hole in bottom of base
- 4. Align spring assembly with bolt fastener
- 5. Screw bolt fastener into bottom of corresponding spring assembly, tighten
- 6. Repeat for second bolt fastener, washer, and spring assembly
- 7. Turn sign frame upright, with base flat on the ground
- 8. Take Allen wrench and tighten set screw inside silver collar on spring shaft, silver collar should be placed at the lowest possible position on the spring shaft at the bottom of the opening
- 9. Repeat for second set screw in silver collar

STEPS 8 & 9



Sign Insertion Instructions



1. Slide sign down through the stay tabs™



2. Slide through, pulling sign in front of bottom slot until sign hits the base

CAUTION: Sign Substrate should weigh no more than 5 lbs. per side.



3. Push sign up into top slot



4. Slide sign down into bottom slot


Fill with up to 115 lbs. of sand to achieve desired wind resistance. Sand should be level inside of base to maintain optimum balance. Shake gently to level sand.




Pounds of Ballast	Head-on
	Wind
	Resistance
70 lbs.	40 mph
100 lbs.	45 mph
115 lbs.	50 mph

Wind Sign II "Quick-Change" Frame

Pounds of Ballast	Head-on Wind
Banase	Resistance
70 lbs.	40 mph
100 lbs.	55 mph
115 lbs.	60 mph



To move sign stand from place to place - grab handle, tilt stand back on wheels, and push sign to move it



Part # 8158 Rev. 3